

Basic Networking Lab

1) **Title:** Basic LAN Setup using Switch in Cisco Packet Tracer

2) **Aim / Objectives :**

To establish communication between two PCs using a Switch in a LAN environment.

3) **Devices Used :**

- 1 Switch (2960)
- 2 PCs
- Copper Straight-through Cables

4) **IP Addressing Table :**

Devices	IP Address	Subnet Mask
PC0	192.168.1.1	255.255.255.0
PC1	192.168.1.2	255.255.255.0

5) **Procedure / Steps :**

- Added one Switch and two PCs in Packet Tracer.
- Connected PCs to Switch using Straight-through Cables.
- Assigned IP addresses to both PCs.
- Verified connectivity using ping command.

6) **Command Used :**

ping 192.168.1.2

7) **Result :**

Successful communication established between both PCs.

8) Concepts Learned :

- LAN communication
- Switch functionality
- IP addressing
- ping testing
- Basic Network Connectivity
- Basic LAN topology
- MAC – based Communication

9) Screenshot :

